

**IMPORTANT SAFETY NOTICE
CONCERNING VENTS FOR NEW FURNACES**

NEWER FURNACES NO LONGER VENT OUT OF A CHIMNEY. INSTEAD THEY VENT OUTSIDE OF YOUR BASEMENT WALL NEAR GROUND LEVEL.

DURING THE WINTER MONTHS, ACCUMULATIONS OF SNOW AND ICE AROUND THIS VENT MAY BLOCK THE VENT AND CAUSE YOUR FURNACE TO SHUT OFF.

MAKE SURE THAT THE VENT IS NOT BLOCKED BY SNOW, ICE OR OTHER MATERIALS AT ALL TIMES. DO NOT BLOW OR DEPOSIT SNOW NEAR THIS VENT.

BE CAUTIOUS ABOUT BLOWING OR DEPOSITING SNOW ONTO YOUR NEIGHBOR'S PROPERTY IN THE AREA AROUND WHERE A FURNACE VENT MAY EXIST.